




Instructions To Modify Original KTM 950SE Side Covers To Suit the 30 litre Safari Fuel Tank



This part needs to be cut off to leave about an 8mm flange.



This part needs to be cut off to leave about an 8mm flange.



This part needs to be cut off to leave about an 8mm flange.



This part needs to be cut off. The part being removed should be about 12mm wide.